

# EXPENDABLE ILLUMINATOR

Mat'l No. 718532 Rev. A

4341 State Street Road Skaneateles Falls, NY 13153 USA Phone: (800) 535-6663 (US Only) or (315) 685-4560 • Fax: (315) 685-3361 www.welchallyn.com

### No. 78600 (Series 58600 Vaginal Specula)


This illuminator is used in conjunction with 58600 and 58601 Disposable Vaginal Specula, Vaginal Speculum Light Handle (78800), and Transformer (73410)

### To prepare for use:

1. Place illuminator on light handle.



- 2. Place illuminator and light handle into slot on 58600/58601 vaginal speculum handle.
- 3. Slide illuminator assembly up until it locks into place.



4. Plug in transformer.



# EXPENDABLE ILLUMINATOR

Mat'l No. 718532 Rev. A

4341 State Street Road Skaneateles Falls, NY 13153 USA Phone: (800) 535-6663 (US Only) or (315) 685-4560 • Fax: (315) 685-3361 www.welchallyn.com

## No. 78600 (Series 58600 Vaginal Specula)


This illuminator is used in conjunction with 58600 and 58601 Disposable Vaginal Specula, Vaginal Speculum Light Handle (78800), and Transformer (73410)

## To prepare for use:

1. Place illuminator on light handle.




- 2. Place illuminator and light handle into slot on 58600/58601 vaginal speculum handle.
- 3. Slide illuminator assembly up until it locks into place.



4. Plug in transformer.

#### To remove illuminator:

- 1. Place thumb at base of illuminator assembly and pull down.
- 2. Pull illuminator off of light handle.





Caution Lamp becomes hot during operation.

### **Cleaning and Sterilization**

The 78600 Expendable Illuminator withstands over 50 cycles of steam autoclaving (270° F, 27 p.s.i., 6 min. cycle). After each time the unit shows degradation of light transmission and eventually needs replacement.


The 78600 Expendable Illuminator may be soaked in the following solutions:

- Cidex/Cidex 7
- Sporicidin
- 70% Isopropyl Alcohol

**Note** Do not use iodine-based soaks (e.g. Betadine, Wescodyne) as these discolor the illuminator and adversely affect light output.

#### To remove illuminator:

- 1. Place thumb at base of illuminator assembly and pull down.
- 2. Pull illuminator off of light handle.





Caution Lamp becomes hot during operation.

# **Cleaning and Sterilization**

The 78600 Expendable Illuminator withstands over 50 cycles of steam autoclaving (270° F, 27 p.s.i., 6 min. cycle). After each time the unit shows degradation of light transmission and eventually needs replacement.

The 78600 Expendable Illuminator may be soaked in the following solutions:

- Cidex/Cidex 7
- Sporicidin
- 70% Isopropyl Alcohol

**Note** Do not use iodine-based soaks (e.g. Betadine, Wescodyne) as these discolor the illuminator and adversely affect light output.